

ASSEMBLY INFORMATION ADDING MINITRIKE SEAT SUPPORT

Here is some information to add the seat support on the **Minitrike** when it is ordered after purchase:

- Fit the support to the central tube, then fit the front part of the trike to the last hole. (Picture 1)
- Insert the screws in the most forward locations (for the shortest version).
- Advance the support against the front part of the trike, then move it back one or two millimeters in relation to the tube of the front part (Picture 2) Once the seat support is positioned correctly and vertically, pre-drill with a 6mm drill bit a hole on one side then the other to be able to fix your support with a screw that goes right through.

On some versions of Minitrike, you may encounter difficulties in fitting the support on the central tube of the trike

- In this case, cut the seat support tube (Picture 3) and move it aside (Picture 4)

Interlocking the support in central tube, then front part



Cutout of the base of the seat support tube with an incision lengthwise

Moving back the seat support by two millimeters



Support spacing for interlocking on the central tube

